



DIGITAL IMAGE PROCESSING PROJECT

Paneer Contamination Detection Using Hyperspectral Imaging and Deep Learning

Presented By

23MIA1074 – Nadia Naureen


23MIA1099 – Divya P

23MIA1130 – Tannya Pasricha

Faculty: Dr Geetha S




Motivation

- Food contamination is a major issue in the dairy industry, especially in perishable products like paneer.
 - Traditional contamination detection relies on manual inspection or chemical testing, which is slow and destructive.
 - There is a need for non-destructive, automated methods to monitor food safety and quality in real time.
- 



Base Paper Summary

“Bread Contamination Detection using Deep Learning and Thermal Imaging”

- Used thermal imaging to detect contaminated regions on bread.
 - Applied YOLO-based deep learning for classification and detection.
 - Achieved high accuracy in identifying contaminated zones through temperature variations.
- 



Our Adaptation

Original Study:

- Food Type: Bread
- Camera Used: Thermal Camera
- Feature Extracted: Temperature Patterns
- Model Used: YOLOv11n



Our Project:

- Food Type: Paneer
 - Camera Used: Hyperspectral Camera (80 Bands)
 - Feature Extracted: Spectral Reflectance
 - Model Used: YOLOv11n (Same as Original Study)
- 

Methodology

Steps Followed:

1. Prepared 3 paneer types – Milkymist, Malai, Tofu.
2. Applied 5 treatments: normal, acetic acid (3 & 6 drops), hydrogen peroxide (3 & 6 drops).
3. Captured 140 HSI images (80 bands each).
4. Processed images using spectral library in Google Colab.
5. Visualized reflectance and pseudo-RGB images.







Results – Visualization & Findings





<u>Treatment</u>	<u>Observation</u>	<u>Spectral Behavior</u>
Normal	Stable intensity	Uniform reflectance
Acetic Acid	Dull surface	Reduced reflectance
Hydrogen Peroxide	Brightened surface	Increased reflectance

- Successfully visualized 140 hyperspectral images in Colab (25–Malai Paneer, 29–Tofu Paneer, 29–Natural Paneer)
- Observed clear differences between normal and treated samples.
- Bands 40–60 showed the strongest reflectance variation.
- Acid-treated cubes: darker spectral regions (lower reflectance).
- Peroxide-treated cubes: brighter spectral zones (higher reflectance).





Natural Paneer



Malai Paneer



Tofu Paneer




RESULT IMAGES

https://drive.google.com/drive/folders/1J8_2B4R58m_Ac6yTE5FEuSctIXSK0IcV?usp=sharing




Key Findings

- Hyperspectral Imaging (HSI) effectively captures chemical and physical changes in paneer.
 - Reflectance variations correspond to contamination or treatment intensity.
 - Data structure and preprocessing pipeline are complete for deep learning integration.
 - The method is non-destructive and more sensitive than thermal imaging.
 - Established dataset and metadata ready for YOLOv11n model training.
- 



Future Enhancements

Planned Next Steps:

- Apply PCA or band selection to compress 80 bands into 3-channel pseudo-**RGB** images.
 - Annotate images using Roboflow for contamination labeling.
 - Train the YOLOv11n model on the preprocessed dataset.
 - Evaluate using *Precision, Recall, and mAP metrics.
 - Extend dataset from 140 to 540 images for higher accuracy.
- 

Future Scope

Real-time paneer quality monitoring in dairy production.

Integration with IoT sensors for smart food safety systems.

Expansion to other dairy products and imaging modalities.



The background features abstract, organic shapes in various shades of brown and tan. These shapes are scattered across the top and bottom edges, with some containing small dots or swirls. Thin, dark brown lines meander across the composition, adding a sense of movement and elegance. The central text is a large, dark brown serif font, standing out against the light tan background.

Thank
You